


iot.pivothead.tv Admins Quick Start Guide



IOT Web Service Portal

Remotely Manage Devices, Users, & Applications



Devices, Users, Applications &
Settings Management



Network & Connectivity
Configuration




Remotely Provision,
Track, Interact

Get Started

Telepresence devices, users, and applications are managed from the IOT web service portal.

Login to <https://iot.pivothead.tv> with email address and password for your PivotSIP™ account. Then, enter the Admin Portal.




Invite Users & Create New Accounts

Invite glasses users and remote experts (app users) to register their account within your private company portal. Or, create new PivotSIP accounts on your own.

Let's start with Invite Users:


1. Go to *PivotSIP Accounts*, then *Invites*, and finally, *Invite*.



2. Enter the user's full name, email address and role in the fields provided, then press the *Submit* button.

Or, create and allocate PivotSIP accounts at your behest:

1. Go to *PivotSIP Accounts*, then press '*Create Account*' button.



Next Page.

Create and allocate PivotSIP accounts continued...

2. Enter information, create account.

Username is case sensitive.
Please use lowercase when creating username.


First Name	<input type="text" value="First name"/>
Last Name	<input type="text" value="Last name"/>
Username	<input type="text" value="username"/>
Email	<input type="text" value="email"/>
Password	<input type="text" value="password"/>
Confirm Password	<input type="text" value="Confirm password"/>
User Role	<input type="button" value="Admin"/>
<input type="button" value="Cancel"/>	<input type="button" value="Create Account"/>

New user will get email with account credentials and support info.

QR Codes for Configuring Devices


Create and send QR Codes for Glasses Users to quickly provision the glasses with account details:

1. Go to *QR Code Generator*.



To receive calls, the glasses need a *PivotSIP™* account and a WiFi connection. To make calls, the device also needs a Speed Dial contact.

2. Choose QR Code Type



Next Page.

QR Codes continued...

3. Enter fields for desired QR Code and *Submit*.

Wifi+PivotSIP+Speed Dial - QR Code

Username	john.doe
Password
Server	sip.pivothead.tv
Wifi SSID	Guest_WiFi
Password
Speed Dial Username	jane.doe

Submit


4. Code can now be scanned from the screen, or sent directly to a glasses user. Once code is scanned, glasses will automatically connect to the internet and be ready for call



Monitor your devices

The device dashboard provides a total inventory of your company devices, and shows which user is associated to each device.

1. Go to *Devices*.



Next Page.

Monitor Devices continued...

- Devices can be managed individually. You can link users to devices, check and change settings, configure connectivity, enable applications, and view device history.

For now, press the *Settings* button next to one of your devices to see status details. This is a helpful tool for troubleshooting with your glasses users in remote locations.

Device Options



For additional setup information and how to videos Pivotvision.com.

Contact the Pivothead Enterprise Support team at enterprisesupport@pivothead.com if you have any questions.